



Información Técnica Planchas Flexográficas Digital DR

Tipo	DR635 LD	DR550 LD	DR470 LD	DR394 -II	DR394 LD
Espesor/mm	6.35	5.5	4.7	3.94	3.94
Dureza/ShoreA	36-38	36-38	36-38	43-45	38-40
Profundidad/mm	2.2-3.0	2.0-3.0	1.8-2.4	1.8-2.0	1.8-2.0
Reproduccion de punto/%	3-98	3-98	3-98	2-98	2-98
Linea/lpi	85	85	85	100	100
Línea aislada/en mm	0.3	0.3	0.3	0.2	0.2
Punto aislado/en mm	0.5	0.5	0.5	0.4	0.4
Exposicion de atras/s 365nm Ultra violeta, 16- 22mw/cm2;24- 30°C	160-- 320	100- 220	80-200	35-60	40--80
Exposicion principal/min 365nm Ultra violeta, 16-	12--24	12--20	12--20	12--20	12--20



22mw/cm2;24-30°C					
Enjuagado/min	10--12	9--12	9--12	5--8	5--8
Secado/h	3--4	3--3.5	2--3	1.5-2	1.5-2
Detackifing/min	5--8	5--8	5--8	5--8	5--8
Exposicion final/min 365nm Ultra violeta, 16-22mw/cm2;24-30°C	5	5	5	5--8	5
Tipo	DR318 LD	DR284 -II	DR284 LD	DR284 M-II	DR254 -II
Espesor/mm	3.18	2.84	2.84	2.84	2.54
Dureza/ShoreA	40-42	46-48	40-42	52-54	54-56
Profundidad/mm	0.9-1.5	1.0-1.4	1.0-1.4	1.0-1.4	1.0-1.2
Reproduccion de punto/%	2-98	2-98	2-98	2-98	2-98
Linea/lpi	100	120	120	120	133
Línea aislada/en mm	0.175	0.175	0.175	0.175	0.15
Punto aislado/en mm	0.25	0.25	0.25	0.25	0.2
Exposicion de atras/s 365nm Ultra violeta, 16-22mw/cm2;24-30°C	30-60	25-40	30-60	25-40	25-40



Exposicion principal/min 365nm Ultra violeta, 16-22mw/cm2;24-30°C	10--20	8--20	10--20	8--20	8--15
Enjuagado/min	5--7	5--7	5--7	5--7	5--7
Secado/h	1.5--2	1.5-2	1.5-2	1.5-2	1.5-2
Detackifing/min	5--8	5--8	5--8	5--7	5--8
Exposicion final/min 365nm Ultra violeta, 16-22mw/cm2;24-30°C	5	5--8	5	4--6	4--6
Tipo	DR228 LS	DR170 LS	DR170 M	DR170 H	DR114 H
Espesor/mm	2.28	1.7	1.7	1.7	1.14
Dureza/ShoreA	56-58	62-64	66-68	70-72	74-76
Profundidad/mm	1.0-1.2	0.7-0.9	0.7-0.9	0.7-0.9	0.6-0.7
Reproduccion de punto/%	2-98	1-98	1-98	1-98	1-98
Linea/lpi	133	150	150	150	150
Línea aislada/en mm	0.15	0.1	0.1	0.1	0.1
Punto aislado/en mm	0.2	0.2	0.2	0.2	0.2
Exposicion de atras/s	35-55	25-40	15-21	15-21	35-70



365nm Ultra violeta, 16- 22mw/cm2;24- 30°C					
Exposicion principal/min 365nm Ultra violeta, 16- 22mw/cm2;24- 30°C	8--20	10--18	10--18	10--18	10--18
Enjuagado/min	5--7	5--7	5--7	5--7	5--7
Secado/h	1.5-2	1.5-2	1.5-2	1.5-2	1.5-2
Detackifing/min	5--7	5--8	5--8	5--8	5--8
Exposicion final/min 365nm Ultra violeta, 16- 22mw/cm2;24- 30°C	4--6	4--6	4--6	4--6	4--6

